

The Goal Alert™ System.

Anchored:

Permanent below-grade anchors, with click-in locks.


Obvious:

A red flag signals loss of ground contact.

Practical:

Disconnecting and reconnecting takes 3 seconds.

Additional anchors enable multiple field configurations.



Preventing Goal Tip-Overs: A Checklist

- **Anchored**: Policies don't protect kids. Anchors do.
- **Obvious**: You need to know when it isn't working.
- **Practical**: Fast & easy, no reason to circumvent or forget.

Example: Seat Belts

- **Anchored**: Seat belts are anchored.
- **Obvious**: Audio alert for unfastened belts.
- **Practical**: Belts are quickly, easily engaged & disengaged.

What isn't working:

	<u>Anchored</u>	<u>Obvious</u>	<u>Practical</u>
Augers*	Yes (Caution not to re-use the same hole.)	Not clear when they've been disconnected or removed.	Difficult and time consuming to move (especially when mowing.)
Stakes*	Changing soil quality (overnight rain) can reduce the holding power to that of a toothpick in a cake.	Not clear when soil quality reduces holding power or when they've been removed.	Require hammers to properly install. Difficult to dislodge (if holding properly.)
Sandbags*	Holding power is limited to the weight of the bag, which is not enough in high winds or if large children climb on the goal.	Not obvious if they've been moved.	Yes

*All three can be easily removed by unauthorized persons.